

If you are using **High Speed cable internet** such as Rogers High Speed Internet, please follow the instructions below:

Step 1: Turn on the modem, Telehop HomePhone Adaptor switches/routers/hubs and all computers:

Step 2: Check the Telehop HomePhone Adaptor to make sure "INTERNET" indicator light on the front panel is ON. If not on, turn everything OFF again, check the connections and change the cables using the cables included with the Telehop HomePhone Adaptor for the INTERNET or ETHERNET until indicator light is on.

Step 3: Try to access the Internet from your computer. If you cannot, call your ISP to release the IP address.

Step 4: Check the system indicator light on the front panel of the Telehop HomePhone Adaptor. If it is ON, you can pickup the phone and make your first call. If the system indicator light is flashing, call our technical support at 1-800-209-4997 for help.

If you are using **High Speed DSL phone internet**, please follow the instructions below:

Step 1: Turn on the modem, Telehop HomePhone Adaptor, all switches/routers/hubs and computers.

Step 2: Check the Telehop HomePhone Adaptor to make sure "INTERNET" indicator light on the front panel is ON. If not, turn everything OFF again, check the connections and change the cables using the two cables included with the Telehop HomePhone Adaptor for the "INTERNET" or "ETHERNET" until indicator light is on.

Step 3: If you have a router, log into the web configuration page of the router and set up the router web interface to be "DHCP". Otherwise, skip this step.

Step 4: Connect one of the computers to the "ETHERNET" port of the Telehop HomePhone Adaptor, and then restart the computer. After you login, open Internet Explorer and type: **http://192.168.0.1** with default password: **telehop**. Click "INTERNET" on the left window, click "PPPoE" on the top window, then change "Enable PPPoE" to "YES" from the dropdown list, then fill in your username and password provided by the ISP. Then click "Save the PPPoE sets", on the bottom, and then click "Reset" at the bottom left.

Step 5: Try to access the Internet from the computer, if you cannot, call your ISP to verify both Username & Password.

Step 6: Check the system indicator light on the front panel of the Telehop HomePhone Adaptor. If it is ON, you can pickup the phone and make your first call. If the system light is flashing, call technical support at 1-800-209-4997 for help.

## PREPARATION

Welcome to Telehop HomePhone! Before installation of your Telehop HomePhone Adaptor, please complete the following preparation.

- You must have **broadband internet** access for the Telehop HomePhone to work.
- Please check your modem from your Internet Service Provider (ISP). If it is using a USB port, please call your ISP to get it replaced with an RJ45 modem before you start.
- Before you set up your network, please check the answers to the questions below. You will need these answers to help you with configuring your Telehop HomePhone Adaptor to your network.

1. High Speed Internet Service Provider: \_\_\_\_\_

2. If you are using High Speed DSL internet, what is your:

Username \_\_\_\_\_ Password \_\_\_\_\_


(If you are not sure, please call your Internet Service Provider (ISP).)

## TELEHOP HOMEPHONE ADAPTOR



**CONNECTING YOUR TELEHOP HOMEPHONE ADAPTOR IF YOU  
DON'T HAVE A ROUTER**

**Warning:** Please turn off all of your computers, modems, routers, hubs and switches before starting and before connecting any cables to avoid potential damage.




Step 1: Connect your ISP Modem to the Telehop HomePhone Adaptor "Internet" port using the straight cable (white cable enclosed).

Step 2: Connect the Telehop HomePhone Adaptor "Internet" port to your computer using your previous cable or the straight cable.

Step 3: Connect a telephone set to the "Phone1" port of the Telehop HomePhone Adaptor.

**CONNECTING YOUR TELEHOP HOMEPHONE ADAPTOR IF YOU  
HAVE A ROUTER**

**Warning:** Please turn off all of your computers, modems, routers, hubs and switches before starting and before connecting any cables to avoid potential damage.



Step 1: Connect your ISP Modem to the Telehop HomePhone Adaptor port using the straight cable (white cable enclosed).

Step 2: Connect the Telehop HomePhone Adaptor port to your computer using the straight cable.

Step 3: Connect a telephone set to the "Phone1" port of the Telehop HomePhone Adaptor.

Step 4: Connect your computers to your router/hub/switch as before.